



**CHARGER CONNECTOR** (on bottom)

Nokia 6021

# Nokia6021

User

Instructions

## Lost/Stolen Equipment

**KEY** 

If your equipment is lost or stolen you must call Cellhire immediately. All calls made are the responsibility of the customer until the line is suspended by the network.

## 24 Hour Technical Support

Cellhire's Support Center is available 24 hours a day, 7 days week:

Within the US: 1 877 244 7242 Outside the US: +1 214 355 5200

support@cellhire.com www.cellhire.com/support

### **Your Mobile Number**



## ► Basic Phone Operation

## Setting up your Nokia phone

Be sure the battery is charged. Your phone is supplied with a dual volt charger (110/220 volt) and an international adapter so it can be charged anywhere in the world.

## To power the phone on/off

Press and hold the power key as shown until phone powers on or powers off.



### To unlock & lock the keypad

To unlock the keypad select Unlock, and press the ex key within 1.5 seconds.

To lock the keypad select Menu, and press the select Menu, and press the key within 3.5 seconds. To answer a call when the keypad is locked, simply press the call key.



Important Note: For your convenience, Cellhire has turned on the automatic key guard for you. The keypad will lock after 1 minute of inactivity. To turn off the automatic key guard press Menu 4832, and select off.

#### To answer & end a call

To answer press the call key. 
To end press the end call key.

#### To redial the last number called

Press the call key twice.

## To make an emergency call

Dial 112 then press the call key.



## To adjust volume

Press the volume keys located on the top-left side of the phone.

## ▶ Dialing Instructions

## Calling a US Number

- 1. Press twice to quickly bring up a + symbol
- 2. Enter the US country code, 1
- 3. Enter the phone number, including area code For example, to call Cellhire Support, dial:



## Calling an international number

- 1. Press \* twice to quickly bring up a + symbol
- 2. Enter the country code for the country you are dialing. See *International Country Codes* section.
- 3. Enter the phone number, including area code (without the first 0)\*

For example, to call a number in the UK dial:



**TIP:** People in the US should dial "011" instead of the + symbol when calling you from a landline

## International Country Codes

Australia	61
Austria	43
Belgium	32
Brazil	55
Canada	1
China	86
Finland	358
France	33
Germany	49
Greece	30
Hong Kong	852
Italy	39

Japan	81
Netherlands	31
Norway	47
Portugal	351
Russia	7
South Africa	27
Spain	34
Sweden	46
Switzerland	41
Taiwan	886
UK	44
USA	1

<sup>\*</sup>Omit the first digit of a non-US phone number if the number starts with a "0"

## VoiceMail Instructions