

# Motorola v860

## User Instructions



### Lost/Stolen Equipment

If your equipment is lost or stolen you must contact Cellhire immediately at [support@cellhire.com](mailto:support@cellhire.com) or call **+1.214.355.5200** (follow the prompts).

All calls made are the responsibility of the customer until the line is suspended by the network.

For a complete users manual please visit:  
[www.cellhire.com/support/equipment-manuals](http://www.cellhire.com/support/equipment-manuals)

### 24 Hour Technical Support

Cellhire's Support Center is available 24 hours a day, 7 days week:

*Within the US:* **1 877 244 7242**

*Outside the US:* **+1 214 355 5200**

[support@cellhire.com](mailto:support@cellhire.com)  
[www.cellhire.com/support](http://www.cellhire.com/support)

### Your Mobile Number

# Motorola v860

## ▶ Basic Phone Operation

Your phone supports *Push-to-Talk* (PTT), which allows you to use your phone like a walkie-talkie to communicate with an individual or group of individuals who are also Verizon Push-To-Talk subscribers.

### To power phone off/on

Press the red Power/End Key until the phone powers off/on.

### Volume adjustments

Press the arrow keys at the side of the phone. The top arrow increases the volume and the bottom decreases volume.

### To make an emergency call

Press 112 and the green Call Key.

### To redial the last number called

Press the green Call Key twice.

### To answer & end a call

To answer press the green Call Key.





To end press the red Power/End Key.

### To make a call

1. Dial the areacode, and the phone number.

## ▶ Push-to-Talk Indicators

When you view PTT contacts and groups, the following indicators beside the entries show their **AVAILABILITY**.

indicator & message	status
 individual available	contact online (available for PTT call)
 individual unavailable	contact offline (unavailable)
 group available	group online (available)
 group unavailable	group offline (unavailable)


The following indicators show **PTT Call Status**:

indicator & message
 Connecting to contact

## ▶ Push-to-Talk Operation

### Activate PTT Mode

1. From the main screen, press the (OK) Key to open the **MENU**.
2. Use the **NAVIGATION** Key to scroll to **SETTINGS & TOOLS** and press (OK).
3. Scroll to **CALL SETTINGS** and press (OK).
4. Scroll to **PTT MODE** and press (OK).
5. Scroll to **ON** and press (OK).

 The signal strength indicator reverses colors when **PTT MODE** is set to **ON** and the phone is registered with the PTT server.

### PTT Calls

**Note:** *PTT MODE must be set to ON to use PTT features. You can make a private PTT call or a group PTT call to other Verizon Wireless® PTT subscribers.*

### You can make two types of PTT Calls:

- **ALERT CALL** - When you place an alert call, the PTT call recipient's phone plays an audible tone and displays a message indicating that someone wants to speak to the recipient. The recipient can accept or decline the call. Alert calls cannot be sent to groups.
- **BARGE CALL** - When you place a barge call, the recipient's phone plays an audible tone, and the call automatically connects. Barge calls, as the caller simply keys the PTT and begins talking. They can be heard over the recipients speaker.

### PTT Call Basics

**To speak** during a PTT call, hold the PTT Key and speak after the tone. Only one person can speak at a time.

**To let others speak**, release the PTT Key.

**To end a call**, press the Power/End Key.

### To Make a PTT Alert Call

1. Dial the PTT recipient's ten digit number or select the recipient from the PTT phone book.
2. Press the Alert Key. Your phone will display **Press PTT Key to Alert**.
3. Press the PTT Key to alert the recipient. Your phone plays "PTT Outgoing Alert" tones and displays **Alerting**.

If the called party answers the alert, your phone displays **Listening To**, and you will hear the called party speaking. If the called party chooses to ignore the alert, or if the phone is unavailable to accept a PTT call, your phone will display **Unavailable**.

When the called party is finished speaking, you will hear the "Floor Available" tone, and your phone will display **Connected To**.

4. Press and hold the PTT Key to talk.
5. Release the PTT Key when finished speaking. This allows the called party to reply.
6. Press the Power/End Key to end the call.

### To Make a PTT Barge Call (no alert given to recipient)

1. Dial the PTT recipient's ten digit number.
2. Press and hold the PTT Key, and listen for the "Ok to Talk" tone. The message **CONNECTED TO** will appear on the main screen. Speak while holding the PTT Key down.
3. Press the Power/End Key to end the call.

### Answer a PTT Call

**Note:** *To receive PTT calls, you must be set PTT MODE to ON.*

### Incoming Barge Call

When you receive a barge call, your phone plays the "Barge" tone. You then hear the calling party speaking. Your phone will display the calling party's wireless number.

1. Press and hold the PTT Key to talk.
2. Release the PTT Key to let the other party talk.
3. Press the Power/End Key to end the call.

### Incoming Alert Call

When you receive an alert, your phone plays the "PTT Alert" tone and displays Incoming Alert, along with the phone number of the calling party. The "PTT Alert" tone repeats every five seconds until answered or ignored, or until twenty seconds have passed.

1. **To answer the alert**, press and hold the PTT Key, and begin talking.  
**To ignore the alert**, press the Ignore Key.
2. Release the PTT Key to let the other party talk.
3. Press the Power/End Key to end the call.

## ▶ VoiceMail Instructions