

Lost/Stolen Equipment

If your equipment is lost or stolen you must contact Cellhire immediately at **support@cellhire.com** or call **+1.214.355.5200** (follow the prompts).

All calls made are the responsibility of the customer until the line is suspended by the network.

For a complete users manual please visit:

www.cellhire.com/support/equipment-manuals

24 Hour Technical Support

Cellhire's Support Center is available 24 hours a day, 7 days week:

Within the US: **1 877 244 7242**

Outside the US: **+1 214 355 5200**

support@cellhire.com

www.cellhire.com/support


▶ International Country Codes

Australia	61
Austria	43
Belgium	32
Brazil	55
Canada	1
China.....	86
Finland	358
France	33
Germany	49
Greece	30
Hong Kong.....	852
Italy	39
Japan	81
Netherlands.....	31
Norway.....	47
Portugal.....	351
Russia	7
South Africa.....	27
Spain.....	34
Sweden	46
Switzerland.....	41
Taiwan	886
UK.....	44
USA.....	1

Nokia6021 SIM Card

Your Mobile Number & User Instructions

Your Mobile Number



Your Cellhire SIM card is activated & ready for insertion into your mobile device.

STEP 1:

To remove the back cover, push the release button (1), and slide the cover towards the bottom of the phone (2).

Remove the back cover.



STEP 3:

Insert the SIM card into the SIM card holder until it snaps into place.

Insert the SIM card.



STEP 5:

Position the battery with the contacts aligned to the golden contacts of the phone. Insert the battery into the battery slot.

Insert the battery.



STEP 2:

Remove the battery by lifting it as shown.


Remove the battery.



STEP 4:

Make sure that the SIM card is properly inserted and that the golden contact area on the card is facing downwards.

SIM card is facing down.



STEP 6:

Align the back cover on the back of the phone (1) with a gap above the top of the back cover of approximately 3 mm. Push the back cover up to the top of the phone to lock it (2).

Replace the back cover.

