

Your Cellhire Device Information:

Lost/Stolen Equipment

If your equipment is lost or stolen you must contact Cellhire immediately at support@cellhire.com or call **+1.214.355.5200** (follow the prompts).

All calls made are the responsibility of the customer until the line is suspended by the network.

For a complete users manual please visit:
www.cellhire.com/support/equipment-manuals

Mifi2352[®]
Novatel

User
Instructions

24 Hour Technical Support

Cellhire's Support Center is available
24 hours a day, 7 days week:

Within the US: **1 877 244 7242**

Outside the US: **+1 214 355 5200**

support@cellhire.com

www.cellhire.com/support

REV 12-01-10

© 2010 Cellhire USA LLC. All rights reserved. Cellhire is a trademark of Cellhire USA.
All other trademarks are the property of their respective owners.

cellhire[®]
international wireless solutions

► How to use your MiFi 2352

In order to get started with your new device, you will need to follow a few simple steps:

1. Turn on Mifi device using the power button.
2. On your computer Search for or view Available wireless connections.
3. Select the One that Reads - **IMHS_2352.XXXX.XXXX**
4. Enter the password located on the bottom of the device, under the battery cover (*normally an 11-digit code*)



MICROUSB CONNECTOR:
Connects to computing devices equipped with a Type A USB port.

SERVICE STATUS INDICATOR (LED):
Visual service status LED indicator that shows you service and data modes. Please see the following page for an explanation of these Service Status LED states.

POWER BUTTON:
Indicates power, battery, and roaming activity.