

## Your Cellhire Device Information:

### Lost/Stolen Equipment

If your equipment is lost or stolen you must contact Cellhire immediately at [support@cellhire.com](mailto:support@cellhire.com) or call **+1.214.355.5200** (follow the prompts).

All calls made are the responsibility of the customer until the line is suspended by the network.

For a complete users manual please visit:  
[www.cellhire.com/support/equipment-manuals](http://www.cellhire.com/support/equipment-manuals)

Mifi2200<sup>®</sup>  
Verizon

User  
Instructions

### 24 Hour Technical Support

Cellhire's Support Center is available  
24 hours a day, 7 days week:

*Within the US:* **1 877 244 7242**

*Outside the US:* **+1 214 355 5200**

[support@cellhire.com](mailto:support@cellhire.com)  
[www.cellhire.com/support](http://www.cellhire.com/support)

REV 12-01-10

© 2010 Cellhire USA LLC. All rights reserved. Cellhire is a trademark of Cellhire USA.  
All other trademarks are the property of their respective owners.

**cellhire**<sup>®</sup>  
international wireless solutions

## ► How to use your MiFi 2200

In order to get started with your new device, you will need to follow a few simple steps:

1. Turn on Mifi device using the power button.
2. On your computer Search for or view Available wireless connections
3. Select the One that Reads - Verizon Mifi 2200 XXXX
4. Enter the password located on the bottom of the device (normally an 11 digit code)



**POWER BUTTON:**  
Indicates power, battery, and roaming activity.

**MICROUSB CONNECTOR:**  
Connects to computing devices equipped with a Type A USB port.

**SERVICE STATUS INDICATOR (LED):**  
Visual service status LED indicator that shows you service and data modes. Please see the following page for an explanation of these Service Status LED states.